



hansen
products

Installation instruction for the Millennium fix window

1. Take out the window from the pallet.



Prepare necessary tools and accessories:



2. Window installation:

2.1. Insert the window into the opening.



2.2. Pre-set the frame and block it by wedges and mounting spacers in the places of mounting holes. Adjust by wedges and make sure that frame is level in all directions.



2.3. Remove masking tape and disassemble glazing beads covers.



2.4. By using spirit level check the vertical and horizontal correctness.



2.5. Check whether the diagonals of the frame are the same - as they should be.



2.6. Drill mounting holes in the wall through the frame.
The numbers of mounting holes is consistent with the number of holes in frame.



2.7. Install mounting screws. Number of screws corresponds to the number of holes in frame



2.8. Check the frame dimensions. If frame has been overtightened, loosen the screw, add spacer and tighten screw.



2.9. Install the glazing beads cover.



Properly installed cover.





* Manual of removing of glazing beads.

Prepare necessary tools:

